

MODEL · I4L

LOAD CELLS AND MILLIVOLTS


Signal converter for load cell and millivolts signals, isolated, for DIN rail mount.

Isolated signal converter for load cell signals and millivolts. Provides +5Vdc excitation voltage to power the load cell, and 'sense' function to compensate for excitation voltage variations. Accepts direct connection of 1, 2, 3 or up to 4 load cells (typical 350 Ohms load cells). Accepts 4 and 6 wire load cells. Accepts unipolar and bipolar ranges up to ± 80 mV. Output signal configurable for 4/20mA (active or passive) and 0/10Vdc. Universal power supply from 18 to 265Vac/dc. 3 way isolation between input, output and power circuits. Plug-in screw terminal connections. Circuit isolation prevents ground loops and transient propagation, protecting remote equipment and signal integrity.

Two configuration modes: ⁽¹⁾ easy and fast using predefined configuration codes, and ⁽²⁾ advanced configuration through the 'configuration menu' to customize input and output signal ranges. Configuration through front push-button keypad and front display. 'Tare' function accessible from front key pad. Configurable display information (tare value, input signal value, output signal value, configured label, signal percentage, process value, excitation voltage and excitation current values). Manual 'force' functions to generate low and high output signals, to validate remote instrumentation during installation. 'Password' function to block non-authorized access to configuration menu. 'SOS' mode to help on critical maintenance and repairs without affecting the manufacturing process. Designed for industrial use, with potential integration into a wide range of applications, excellent quality and optional customization.


1. TECHNICAL SPECIFICATIONS

Input signal ranges for load cells	
signal ranges	from 0/5 mV up to 0/80 mV
bipolar signal ranges	from ± 5 mV up to ± 80 mV
excitation voltage	+5 Vdc
excitation voltage variations	automatic compensation
excitation current	max. 70 mA
Input signal ranges for millivolts	
signal ranges	from 0/5 mV up to 0/80 mV
bipolar signal ranges	from ± 5 mV up to ± 80 mV
excitation voltage	no
input impedance	10 MOhm typical (with 1 MOhms during 150 milliseconds, every 10 seconds approx.)
Accuracy at 25 °C*	
see section 7 for each type of signal	
*values for 4/20 mA output, for 0/10 Vdc output, add +0.05 % to indicated accuracy.	
Thermal stability	
	± 150 ppm/°C (F.S.) for ranges up to 5 mV
	± 100 ppm/°C (F.S.) for ranges up to 20 mV
	± 75 ppm/°C (F.S.) for ranges up to 80 mV
Step response	
with 'no filter'	<115 mSec. typ. (0% to 99% signal)
with '50 Hz filter' or '60 Hz filter'	<150 mSec. typ. (0% to 99% signal)
with '50 and 60 Hz filter'	<300 mSec. typ. (0% to 99% signal)
Output signal ranges	
active current output	4/20 mA active, max. <22 mA, min. 0 mA, load < 400 Ohm
passive current output	4/20 mA passive, max. 30 Vdc on terminals
voltage output	0/10 Vdc, max. <11 Vdc, min. -0.05 Vdc (typ.), load > 10 KOhm
* custom input and output ranges through the 'configuration menu' (for example: 4/12 mA, 0/5 Vdc, 20/4 mA, etc)	
Configuration system	
key pad + display	accessible at the front of the instrument
configuration modes	⁽¹⁾ through preconfigured codes, ⁽²⁾ through 'configuration menu'
Power supply	
voltage range	18 to 265 Vac/dc isolated (20 to 240 Vac/dc $\pm 10\%$)
AC frequency	45 to 65 Hz
consumption	<3.0 W
power wires	1 mm ² to 2.5 mm ² (AWG17 to AWG14)
overvoltage category	2
Isolation	
input - output	3000 Veff (60 seconds)
power - input	3000 Veff (60 seconds)
power - output	3000 Veff (60 seconds)
Environmental	
IP protection	IP30
impact protection	IK06
operation temperature	from 0 to +50 °C
storage temperature	from -20 to +70 °C
'warm-up' time	15 minutes
humidity	0 to 95% non condensing
altitude	up to 2000 meters

2. HOW TO ORDER

I4L	Load cell signal converter
I4L.1442	Load cell signal converter with custom features


3. DIMENSIONS



Mechanical	
size	106 x 108 x 22.5 mm
mounting	standard DIN rail (35 x 7.5 mm)
connections	plug-in screw terminals (pitch 5.08 mm)
housing material	polyamide V0
weight	<150 grams
packaging	120 x 115 x 30 mm, cardboard

4. CONFIGURATION SYSTEM

The instrument allows for 2 configuration modes: ⁽¹⁾ easy and fast using predefined configuration codes, and ⁽²⁾ advanced configuration through the 'configuration menu'. Configuration is applied through the 3 push button keypad and the 4 red digit led display at the front of the instrument.



- Key 'SQ' (■)
- Key 'UP' (▲)
- Key 'LE' (◀)
- Display

5. FUNCTIONS INCLUDED

- 'Force' functions temporarily forces the signal output to the minimum (**Force Low**), to the maximum (**Force High**) or to a selectable value (**Force Set**), to validate the function of the remote elements connected to the output during installation.
- 'Label' function configure an alphanumerical label to be shown on display, and easily identify each unit.
- 'SOS' mode manually set the output to a fixed value, to apply critical maintenance or repairs to the input signal section without affecting the manufacturing process.
- 'Messages' function configure information to display at your request at front key 'LE' (◀). See real time values for input signal, output signal, input percentage, process value or configured label.
- 'On error' function configure the output response in case of error at the input.
- 'Password' function prevents access from unauthorized operators to 'configuration menu'.

6. CONNECTIONS: INPUT & OUTPUT




Table 1 | INPUT signal connections

Input signal	Input terminals					
	1	2	3	4	5	6
load cell	Vexc-	sense-	signal-	Vexc+	sense+	signal+
millivolts			mV-			mV+

Table 2 | OUTPUT signal connections

Output signal	Output terminals			Connections
	7	8	9	
4/20mA active output		mA- (in)	mA+ (out)	
4/20mA passive output* (*external loop power needed).	mA+ (out)	mA- (in)		
0/10Vdc	common		+Vdc	

7. PRECONFIGURED SIGNAL RANGES AND TYPICAL APPLICATIONS

The instrument has 2 different configuration modes: ⁽¹⁾easy and fast using predefined configuration codes, and ⁽²⁾advanced configuration through the 'configuration menu'.

The tables below provide a list of preconfigured input signal ranges, together with technical specifications for each range, and the associated preconfiguration codes. The 'configuration menu' allows to configure custom ranges for both the input and the output ranges. For additional information see the 'User's Manual' (see section 8).

Typical applications

- load cells that provide a 1 mV/V, 2 mV/V or 3 mV/V signals and can be powered from the instrument +5Vdc excitation voltage.
- direct measurement of millivolt signals with ranges up to 0/80mV and down to 0/5mV.

- direct measurement of bipolar millivolt signals with ranges up to ±80mV and down to ±5mV.



Tables below indicate the preconfigured ranges for input and output signals. Use the 'configuration menu' to configure custom input and output ranges. For additional information see the User's Manual (see section 8).

Table 3 | Input ranges and technical specifications for load cell signals

Sensor	Code for 4/20 mA output	Code for 0/10 Vdc output	Accuracy (% FS)	Max. oversignal	Zin
0/5mV	010	110	<0.18%	±12Vdc	20M0hm
0/10mV	011	111	<0.13%	±12Vdc	20M0hm
0/15mV	012	112	<0.13%	±12Vdc	20M0hm
0/20mV	013	113	<0.10%	±12Vdc	20M0hm
0/25mV	014	114	<0.10%	±12Vdc	20M0hm
0/30mV	015	115	<0.10%	±12Vdc	20M0hm
0/40mV	016	116	<0.10%	±12Vdc	20M0hm
0/50mV	017	117	<0.08%	±12Vdc	20M0hm
0/60mV	018	118	<0.08%	±12Vdc	20M0hm
0/70mV	019	119	<0.08%	±12Vdc	20M0hm
0/80mV	120	120	<0.08%	±12Vdc	20M0hm
±5mV	121	121	<0.15%	±12Vdc	20M0hm
±10mV	122	122	<0.10%	±12Vdc	20M0hm
±20mV	123	123	<0.10%	±12Vdc	20M0hm
±30mV	124	124	<0.10%	±12Vdc	20M0hm
±40mV	125	125	<0.08%	±12Vdc	20M0hm
±50mV	126	126	<0.08%	±12Vdc	20M0hm
±60mV	127	127	<0.08%	±12Vdc	20M0hm
±70mV	128	128	<0.08%	±12Vdc	20M0hm
±80mV	129	129	<0.08%	±12Vdc	20M0hm


Table 4 | Input ranges and technical specifications for millivolt signals

Sensor	Code for 4/20 mA output	Code for 0/10 Vdc output	Accuracy (% FS)	Max. oversignal	Zin
0/5mV	050	150	<0.15%	±12Vdc	10M0hm
0/10mV	051	151	<0.10%	±12Vdc	10M0hm
0/15mV	052	152	<0.10%	±12Vdc	10M0hm
0/20mV	053	153	<0.07%	±12Vdc	10M0hm
0/25mV	054	154	<0.07%	±12Vdc	10M0hm
0/30mV	055	155	<0.07%	±12Vdc	10M0hm
0/40mV	056	156	<0.05%	±12Vdc	10M0hm
0/50mV	057	157	<0.05%	±12Vdc	10M0hm
0/60mV	058	158	<0.05%	±12Vdc	10M0hm
0/70mV	059	159	<0.05%	±12Vdc	10M0hm
0/80mV	060	160	<0.05%	±12Vdc	10M0hm
±5mV	061	161	<0.12%	±12Vdc	10M0hm
±10mV	062	162	<0.07%	±12Vdc	10M0hm
±20mV	063	163	<0.07%	±12Vdc	10M0hm
±30mV	064	164	<0.07%	±12Vdc	10M0hm
±40mV	065	165	<0.05%	±12Vdc	10M0hm
±50mV	066	166	<0.05%	±12Vdc	10M0hm
±60mV	067	167	<0.05%	±12Vdc	10M0hm
±70mV	068	168	<0.05%	±12Vdc	10M0hm
±80mV	069	169	<0.05%	±12Vdc	10M0hm

8. ADDITIONAL DOCUMENTATION

User's manual	www.fema.es/docs/5583_I4L_manual_en.pdf
Datasheet	www.fema.es/docs/5585_I4L_datasheet_en.pdf
Quick installation guide	www.fema.es/docs/5587_I4L_installation_en.pdf
Web	www.fema.es/docs/Series_I4

9. OTHER SIGNAL CONVERTERS ... AND MORE



SERIES I3

Section **OEM**

output signal 4/20 mA, 0/10 Vdc
 configuration by codes (inside)
 isolation 3 ways



SERIES I4

FULLY CONFIGURABLE

output signal 4/20 mA, 0/10 Vdc, ...
 configuration menu (front keypad)
 isolation 3 ways



SERIES I5

FIELD BUS

output signal Modbus RTU, CANbus, ...
 configuration by menu (front keypad)
 isolation 3 ways



SERIES B

LARGE FORMAT DISPLAYS

digit 60 and 100 mm
 reading 25 and 50 meters
 mounting wall, panel, hanging
 housing metallic, IP65

50 YEARS 1969-2019	Q ISO 9001 Certified Quality	CE EN-61010-1 Security	CE EN-61326-1 Electromagnetic C.	5 YEARS Extended Warranty
---------------------------------	---	-------------------------------------	---	--



FEMA ELECTRÓNICA, S.A.
 Altimira 14 - Pol. Ind. Santiga
 E08210 Barberà del Vallès
 BARCELONA - SPAIN
 Tel. +34 93.729.6004
 info@fema.es
 www.fema.es

Process	Temperature	Counter	Weight	Flow	Time
Frequency	Temperature	Speed	Vac	Aac	Integrators
Potentiometer	Temperature	Period	Aac	Vdc	Resistances
Digital	Digital	Digital	Digital	Custom	